Barber Dirty Bomb Manual.

Controls are Volume, Treble, Bass and Gain. With an internal Bass Boost trim pot.

Here are some suggested settings, please keep in mind these are only general suggestions and your best tones will be found by experimenting and dialing in your favorite tone; the numbers indicate a clock face style setting, so 2:30 means "two thirty".

70's Rock; Volume; 1, Treble 1, Bass 3, Gain 8, internal bass pot 12, toggle center.

Dynamic Rock; Volume 2:30, Treble 1:30, Bass 2, Gain 8, internal bass 1, toggle right.

Young 90's; Volume 1:30, Treble 1, Bass 2:30, Gain 1:30, internal bass 1, toggle left.

Big 80's; Volume 1, Treble 2:30, Bass 4:30, Gain 3, internal bass 2, toggle left.

Drop D; Volume 1:30, Treble 3:15, Bass 5, Gain 5, internal bass 2:30, toggle right.

Fat Lead; Volume 12, Treble 2, Bass 5, Gain 4:30, internal bass 3, toggle center.

Booster; Volume 5, Treble 11:30, Bass 9:30, Gain 7, internal bass 10, toggle left.

Touch Obsession; Volume 1:30, Treble 2, Bass 3:30, Gain 8, internal bass 2, toggle center.

Very Heavy, Very Tight; Volume 1, Treble 2, Bass 4, Gain 5, internal bass 4:30, toggle right.

Functions

- 1. Volume adjusts overall level of the Dirty Bomb.
- 2. Treble adjusts brightness. This control is very powerful and is useful for the entire sweep. Always start low and work your way up.
- 3. Bass adjusts the low frequency content. This control is also very powerful, explore the whole range and find the matching treble setting. Use the highest setting of this control to add a low midrange "thickness".
- 4. Gain adjusts the amount of distortion, sustain and harmonics.
- 5. Toggle: This control sets the balance of the EQ midrange; left is neutral, center is mid bumped and right is mid scooped
- 6. Internal Bass Boost, this control is inside the unit, located to the right side. Match this to your amp and playing style, the highest settings could be challenging to some speakers, in that case, back off until you have the clarity you need.

Additional notes

Please use a <u>9 volt negative tip</u> power supply (not included), or a 9v battery (not included).

Questions? Help? Email us at <u>sales@barberelectronics.com</u> Or call 717-630-9191

www.barberelectronics.com

Barber Electronics 25 Kenlee Circle Hanover, PA 17331

Thank you for purchasing the Barber Electronics Dirty Bomb.